

CAPTO should have a periodic inspection performed by a competent person at least once every 12 months, after any exceptional event(s), or if there is any doubt to the condition of the product. For each inspection, CMC recommends this Periodic PPE Inspection Form be completed, signed, and archived for the life of the product. In case of retirement, destroy the device to prevent further use.

REFERENCE DOCUMENTS, available at cmcpro.com	REQUIRED TOOLS & EQUIPMEN	IT DOCU	MENTATION			
- CAPTO User Manual	- A new, unused CAPTO for compar	rO for comparison				
- CAPTO Inspection Procedure		e acceptable parameters for the CAPTO				
- CAPTO Periodic PPE Inspection Form (this document)	•	(see the back of the device or User Manual) - Documentation of product history from the user				
USER INFORMATION						
NAME	PHONE					
ASSOCIATION	ADDRESS					
E-MAIL						
PRODUCT INFORMATION						
PRODUCT NAME	DATE OF PURCHASE					
LOT NUMBER	DATE OF FIRST USE					
MANUFACTURE DATE	LAST INSPECTION					
MODEL NUMBER						
INSPECTION		PASS	MONITOR	FAIL		
VISUAL INSPECTION						
- Check that the product number is present and legible.						
- Check that the CE certification mark is present and legible.						
 Visually compare the device with a new device and check to modified parts. 	make sure that there are no missing or	\bigcirc	0	\bigcirc		
 Carefully inspect the entire device for signs of damage such a or excessive wear. Check for any sharp edges, especially in t 						
CAM MOVEMENT						
- Ensure the cam rotates freely, with minimal friction, and close	ses by itself when released in the					
open position. - Verify that the cam does not have excessive (≥1mm) play ab	out its axle by pulling and pushing radially	0	<u> </u>	\sim		
from the pivot point.		\circ	0	\bigcirc		
 Inspect the rivet of the Cam Axle (back of device) for loosene of this joint. 	ess or damage. Ensure that there is no play					

SIDE PLATE RELEASE LATCH / SIDE PLATE MOVEMENT AND FUNCTION			
- While holding the Moving Side Plate closed, manually manipulate the latch. Ensure the Side Plate Release Latch moves freely with minimal friction.			
- Verify the Side Plate Release Latch returns to the closed position when released from the open position.			
- Inspect the rivet of the Side Plate Release Latch for looseness or damage. Ensure that the Side Plate Release Latch is firmly attached to the Moving Side Plate.			
- When opening the Moving Side Plate, verify that it takes two defined motions of the Side Plate Release	-	-	-
Latch to open the device fully. If the latch function becomes impaired, apply lubricant as indicated in the	\mathcal{O}	O	O
User Manual under Carrying, Storage, and Transport.			
- Check the latch pins (2) in the Chassis. Check that they are flush with the surface of the Chassis and ensure they are not excessively worn where they contact the Side Plate Release Latch.			
- Verify that when the Moving Side Plate is fully open that the cam is also brought to its fully open position.			
- Inspect the rivet of the Moving Side Plate for looseness or damage. Ensure that the Moving Side Plate is			
firmly attached to the Cam Axle. Play that could prevent the closing of the Moving Side Plate is unacceptable.			
- Close the Moving Side Plate by pushing it into the closed position. The Side Plate Release Latch should			
make two successive clicks and securely lock the Moving Side Plate.			
PULLEY ASSEMBLY			
- Ensure that the sheave can rotate with minimal friction.			
 Radial play of the sheave greater than 1mm is unacceptable. 	\bigcirc	\circ	\bigcirc
- Verify that the Pulley Flange is firmly attached to the Chassis.			
FUNCTION CHECK			
- Install CAPTO on an anchored rope within the acceptable diameter range as indicated on the			
device or within the User Manual.			
- Ensure CAPTO moves freely towards the anchor, and grabs the rope when pulled away from	\bigcirc	\bigcirc	\bigcirc
the anchor.			

RESULTS

DISPOSITION	O PASS	⊖ FAIL			
INSPECTION D			REASON FOR INSPEC		
COMMENTS					
INSPECTOR NA	AME		INS	SPECTOR SIGNATURE	

By performing a periodic inspection and signing periodic inspection forms, you are declaring yourself as a competent person and assuming responsibility for the implementation of the inspection processes and proper disposition of the PPE.

CMC Rescue, Inc. 6740 Cortona Drive Goleta, CA 93117, USA 805-562-9120 / 800-235-5741 cmcpro.com ISO 9001 Certified ©CMC Rescue, In. All rights reserved. CMC and X are registered marks of CMC Rescue, Inc. Control No. 33601XML01